



# WebRail Heavy Vehicle Fall Protection System Instructions & Safe Use

## Tegral Transport Equipment

1300 159 809  
02 4868 1255

77-83 Lytton Rd Moss Vale  
NSW 2577


[sales@tegral.com.au](mailto:sales@tegral.com.au)  
[www.tegral.com.au](http://www.tegral.com.au)




SpanSet  
Certified  
Safety




1. Ensure posts are fitted securely to the truck body.
2. Connect the double action hook to the anchorage point on the end post located at the cab end of the vehicle.
3. Fit the webbing through the intermediate posts, ensuring the webbing is not twisted.
4. Attach the other end of the assembly to eyes located on the end posts at the rear of the truck.



5. Pull the webbing through the ratchet, ensure the TFI is in the correct orientation, then tension the ratchet until the TFI indicates 250 daN, tension is applied.



**CORRECT ORIENTATION OF TFI**



- 6. Stow excess webbing securely
- 7. Repeat for all WebRail straps

## WebRail Inspection

---

**Before use the WebRail System should be inspected by the user.**

### Webbing


Check the webbing for any cuts, abrasions, heat or chemical damage.

### Hooks

Inspect the hooks for corrosion or deformation and make sure the gate operates correctly.

### Ratchet

Inspect the ratchet for corrosion, deformation or heat damage and make sure the ratchet operates correctly.



## Tegral Transport Equipment

77-83 Lytton Rd  
Moss Vale  
NSW 2577

1300 159 809  
sales@tegral.com.au  
www.tegral.com.au



*Loads easier*

**Tegral Transport Equipment**

77-83 Lytton Rd  
Moss Vale  
NSW 2577

1300 159 809  
sales@tegral.com.au  
www.tegral.com.au

